

Bosch Motorsport **ECU MS 4 Sport** Manual

F 02U 002 562-02



BOSCH

Invented for life



Content

1 Getting started.....	4
2 Sport Systems – Overview	5
3 ECU MS 4 Sport	6
3.1 Input Channels:	7
3.2 Output Channels:	8
3.3 Power supply.....	9
3.4 Ignition trigger wheel	10
3.5 Mounting position of the speed sensors.....	11
3.6 Sensor recommendation Clubsport.....	12
4 Starting up the ECU	14
4.1 Offline Data Application	14
4.1.1 Basic engine data	14
4.1.2 Injection: INJCALC	16
4.1.3 Injection Controls.....	18
4.1.4 Ignition: IGNCALC	18
4.1.5 Inj + Ign Controls:	19
4.2 Online Data Application.....	20
4.2.1 PRESSURES.....	20
4.2.2 TEMPERATURES	20
4.2.3 LAMDET	20
4.2.4 GEARDET	20
4.2.5 ATHDET	21
5 Extensibility	21
6 Activation of Softwareoptions	22

1 Getting started

Important Notes:

Use the ECU MS 4 Sport only as intended in this manual. Any maintenance or repair must be performed by authorized and qualified personnel approved by Bosch Motorsport.

Operation of the ECU MS 4 Sport is only certified with the combinations and accessories that are specified in this manual. The use of variant combinations, accessories, and other devices outside the scope of this manual are only permitted when they have been determined to be compliant from a performance and safety standpoint by a representative from Bosch Motorsport.

For systems with drive-by-wire additional safety provisions apply. For details please refer to the document „Safety Instructions for Drive-by-Wire Systems in Motorsport Applications“.

Disclaimer:

Due to continuous enhancements we reserve the rights to change any illustrations, photos and technical data within this manual.

Please retain this manual for your records.

Edition: February 12


Before starting:

Before starting your engine for the first time, install the complete software from the installation CD. Bosch Motorsport software is developed for Windows 2000/XP. Connect the PC Link Adapter (MSA Box) or the Ethernet line (depending on calibration equipment) to your computer and install the driver. Read the manual carefully and follow the application hints step by step. Don't hesitate to contact us, contact data can be found on the backside of this document.

2 Sport Systems – Overview

The Sport Systems support an easy to understand user concept. The ECUs are configured as so called Alpha/N versions. This means that the engine characteristic map is based on engine speed, throttle position, and engine temperature. The injected amount of fuel and the ignition point are derived from these values.

Gasoline Direct Injection (GDI)




ECU MS 3 Sport, MS 4 Sport, MS 4.4 Sport



Communication Interface MSA-Box II



Calibration Software Modas Sport



CAN/
K-Line


USB

CAN

Display DDU 7 or Logger C 50



Configuration and Analysis Software WinDarab



CAN/Ethernet

3 ECU MS 4 Sport

The MS 4 Sport is an engine management system for high performance engines up to 8 cylinders. The system contains 8 ignition drivers for external power stages and 8 independent injection power stages. Two independent wide range lambda circuits allow lambda closed loop engine control. There is also a version for Turbo engines, Turbo GDI engines as well as for motorcycle engines available. Various engine parameters can be measured with different input channels and transferred via CAN interface to an optional data logger.



Application	
Control strategy	alpha/n
Lambda control	dual
Speed limiter	✓
Gear cut for sequential gear box	✓
Map switch (3 positions - each corresponds to different target lambda and spark maps)	✓
Fuel cut off	✓
Asymmetric injection timing	✓
Asymmetric ignition timing	✓
Support of 60-2 and 36-2 ignition trigger wheels	
Max. vibration	<i>Vibration Profile 2</i> (see Appendix or www.bosch-motorsport.com)

Mechanical Data	
Sheet-metal housing	
Each connector pin individually filtered	
Vibration damped circuit boards	
Size	180 x 162 x 46 mm
Weight	430 g
Temperature range	-40 ... 75 °C

Connectors	
Mating connector I	D 261 205 344
Mating connector II	D 261 205 345

Electrical Data	
Max. power consumption	30 W at 14 V
Inputs	
2 lambda sensor interfaces LSU	
4 inputs for Hall-effect wheel speed sensors	
1 input for inductive crankshaft sensor	
1 input for Hall-effect camshaft sensor	
25 analog inputs 0 ... 5 V	
2 knock sensor inputs	
Outputs	
8 injection power stages	
8 ignition drivers	
10 power stages (2.7 A/0.6 A; low side; PWM)	
2 power stages for lambda heater	
1 H-bridge (5 A)	
2 sensor supply	5 V/100 mA
Communication interfaces	
1 K-line serial interface	
2 CAN interfaces for external communication	
Software	
Modas Sport Calibration Software	inclusive
WinDarab Analysis Software	on request

Optional Accessories

MSA-Box II
Data logger C50
Display DDU 7
Injection power stage HPI 5
HP fuel pump HDP 5

Optional Functionality

Advanced Turbo Boost Control	F 02U V00 781-01
Knock Control SW upgrade	F 01T A20 053-01
Electronic Throttle Control SW upgrade	F 01T A20 051-01
Electronic Throttle Control incl. shift down (Blipper) SW upgrade, compatible with MEGA-Line gearbox control	F 02U V00 780-01
Traction Control SW upgrade	F 01T A20 052-01
Variable Valve Timing VVT SW upgrade	F 02U V00 395-01

Part Numbers

MS 4 Sport	F 01T A20 049-02
MS 4 Sport GDI (in combination with injection power stage HPI 5)	F 02U V01 138-01
MS 4 Sport Turbo	F 01T A20 060-01
MS 4 Sport Turbo GDI (in combination with injection power stage HPI 5)	F 02U V01 000-01
MS 4 Sport Motorcycle	F 02U V00 024-01

MS 4 Sport Product Variations

	MS 4 Sport	GDI	Turbo	Turbo GDI	Motorcycle
Max. cylinders/max. banks	8/2	8/2	8/2	6/2	4/2
GDI support	-	+	-	+	-
ABS M4-interface	+	+	+	+	-
Turbo boost control	-	-	+	+	-
Advanced turbo boost control	-	-	optional	optional	optional
Knock control	optional	optional	optional	optional	-
Electronic throttle control	optional	optional	optional	optional	-
Shift down (Blipper)	optional	optional	optional	optional	-
Traction control	optional	optional	optional	optional	-
Variable valve timing VVT	optional	optional	optional	optional	-

3.1 Input Channels:

There are several inputs for temperature measurements e.g. engine temperature *tmot* or intake air temperature *tair*. Temperature inputs have an internal “pull up” resistor for use with a NTC sensor (negative temperature coefficient). Depending on the used sensor (e.g. 15 KOhm or 2.5 KOhm NTC) the corresponding linearization curve has to fit.

For measuring of throttle position *ath* or pressures f.e. *pfuel*, *poil*, which deliver a voltage (active sensors), pull up resistors are not allowed. These sensors must be calibrated with the sensors offset and sensitivity values (printed on the sensor, if using Bosch parts).

The ECU MS 4 Sport needs an inductive speed sensor on the ignition trigger wheel. For the camshaft sensor a Hall Effect sensor is necessary. Also for wheel speed measurement Hall Effect sensors are recommended. 4 Hall Effect wheel speeds can be connected directly to the ECU.


For the wide range lambda measurement & control, the lambda sensor Bosch *LSU 4.9* is needed.

3.2 Output Channels:


The ECU MS 4 Sport has 8 independent injector power stages. These output drivers can deliver a maximum current of 2.2 Ampere. Therefore the injection valves must have at least 6 Ohm internal resistance. A few Bosch injection valves have an internal resistance of just 1.2 Ampere. These types can not be used here.

The 8 ignition drivers supply the signal to drive external ignition power stages. (Most of the modern coils have integrated power stages)

The wiring for coils with **integrated** power stages is shown in the following picture on the left side, the wiring for coils with **external** power stages is shown on the right side.



Integrated power stages



External power stages

A typical 6 cylinder engine with firing order 1-5-3-6-2-4 is connected as follows:

Firing	1	5	3	6	2	4
IGN	A	B	C	D	E	F
INJ	A	B	C	D	E	F

3.3 Power supply

The ECU MS 4 Sport requires an external main relay to be wired to the harness. This relay is controlled by the ECU MS 4 Sport to realize that important information can be stored after switching off the ignition.


Please ensure that you have a good ground installation. That means:

- A ground that has a solid, low resistance connection to the battery minus terminal.
- Connection should be free from dirt, grease, paint, anodizing, etc.
- Cylinder heads make a good grounding point
- Use large diameter wire
- More metal-to-metal contact is better!

The following notations for power signals are used:


- KL15 is a switched battery rail controlled by the ECU driver
- KL30 is an unswitched battery positive rail (same as battery positive terminal)
- KL31 is an unswitched ground rail (same as battery negative terminal)

Be careful to observe current limits of wires and connector pins!




3.4 Ignition trigger wheel

The camshaft trigger sensor is a Hall-effect type with a single tooth trigger wheel.



The software assumes a 60-2 teeth or a 36-2 teeth trigger wheel for proper operation. The type can be chosen in the software. The crankwheel trigger sensor must be an inductive type for default configuration. For the camshaft sensor a hall sensor must be used. The picture below shows the correct installation position.




Symbol	Benennung	Nennabmessungen
Z	Zähnezahl	60 (-2)
D	Durchmesser	> 100 mm
h1	Zahnhöhe	3,5 mm
h2	Lückenhöhe	h1/2
AG	Luftspalt	0,8 ± 0,3 mm
t	Zahnraddicke	> 5,0 mm
δ	TDC - REF	frei wählbar
β	Lückenbreite	3,30°
φ	Zahnbreite	2,70°

Symbol	Description	Nominal Dimension
Z	tooth count	36 (-2)
D	diameter	> 95,3 mm [3.750 in]
h1	tooth depth	5,0 mm [0.197 in]
h2	gap depth	h1/2
AG	air gap	0,8 ± 0,3 mm
t	wheel thickness	> 5,0 mm [0.197 in]
δ	TDC to REF	frei wählbar
β	gap width	5,55°
φ	tooth width	4,45°

3.5 Mounting position of the speed sensors

Procedure to find the right position for the crank and cam triggers:

1. Rotate the engine to the precise position of TDC compression for cylinder #1.
2. Rotate the engine (*) crankshaft degrees backwards.
3. Adjust the position of the crank trigger wheel in reference to its inductive speed sensor: the longitudinal axis of the sensor must point exactly towards the reference mark (2nd falling edge after the gap).
4. Adjust the position of the cam trigger in reference to its hall effect speed sensor: the sensor must be about at the center of the tooth.
5. Turn the engine by 360 crankshaft degrees to reach the position of (*)° before TDC exhaust for cyl. #1.
6. Verify that the crank trigger reference mark is in alignment with the longitudinal axis of the sensor (same as Step 3) and that the cam trigger tooth is at the opposite side of its speed sensor.



Please note:

- All angles are shown and indicated in crankshaft degrees.
- The width of the cam trigger tooth is not important, however it must be wide enough to ensure a safe overlap of the crank trigger reference mark at any time.
- The hall effect signal is the inversion of the shape of its cam trigger: the tooth effects a 'low' signal at the sensor and vice versa.
- With 4 and 6 cylinder engines, the value of 66 degrees must be replaced by 78 degrees.

3.6 Sensor recommendation Clubsport

The sensors shown on this page are partly based on production type parts and proofed hundreds of times in races all over the world. They offer good value for money.



NTC M12-L



NTC M12-H



TCP-K



PSA-C



PSS-10



LSU 4.9



IA-C



HA-P



RP 86



RP 100 twin



KS-P



RP 308



GSS-2



AM 600-3



YRS 3



Model	Range of application	Connector Loom	Part No.
NTC_M12-L	Ambient air temperature	D 261 205 288	0 280 130 039
NTC-M12-H	Fluid temperature (oil, water, fuel)	D 261 205 337	0 281 002 170
TCP-K	Exhaust gas temperature	ASL 0-06-05SD-HE	B 261 209 385
PSA-C	Ambient air pressure	D 261 205 289	0 261 230 037
PSA-C	Crankcase pressure	D 261 205 289	0 261 230 037
PSS-10	Fluid pressure (oil, water, fuel)	1 928 403 968	B 261 209 341
PSA-C	Air pressure (manifold, boost)	D 261 205 289	0 281 002 389
LSU 4.9	Lambda value	D 261 205 356-01	0 258 017 025
IA-C	Crankshaft revolutions	D 261 205 334	0 261 210 136
HA-P	Camshaft revolutions	D 261 205 335	0 232 103 037
HA-P	Wheel speed	D 261 205 335	0 232 103 037
RP 86	Throttle angle	D 261 205 334	0 280 122 016
RP 100 twin	Acceleration pedal angle	AS 0-07-35SN	B 261 209 591
KS-P	Knock	D 261 205 337	0 261 231 120
RP 308	Gear detection	ASL 0-06-05SA-HE	B 261 209 570
GSS-2	Gear shift	ASL 0-06-05SC-HE	B 261 209 227
AM 600-3	Acceleration	ASL 0-06-05SA-HE	B 261 209 313-01
YRS 3	Yaw rate	F 02U 002 235-01	0 265 005 838
RP 308	Steering angle	ASL 0-06-05SA-HE	B 261 209 570

The volume of applied sensors may differ depending on individual software extents.

4 Starting up the ECU

4.1 Offline Data Application

The following chapter deals only with the main parameters which should be checked before a first engine startup. Several functions are recommended to be switched off, many software labels will not be explained in detail. To work on these functions and labels after the first startup, please refer the full-scope function description.

The Offline data application guide shall help to get the engine started the first time without problems.

Important hint

- Wrong engine setup data may lead to serious engine damages! If the TDC angles do not match the expected configuration of a symmetrical or V engine the setup won't be accepted and for safety reasons the engine will not start (engsetupOK_b = 0).

4.1.1 Basic engine data

How many cylinders does the engine have?

The new Clubsport System can be used for engines with different number of cylinders using the same program.

How many teeth does the crankshaft wheel have?

The System supports wheels with 60-2 or 36-2 teeth. The TDC angles are defined starting from the second tooth after the gap in the rotating direction. The first cylinder in the firing order should have its TDC after the gap.

Is the ignition symmetrical? If not, how are the angles defined?

Engines with 6 and 8 cylinders can have a V configuration which in some cases requires unsymmetrical ignition angles. The Clubsport Software supports any variation but you must define the TDC angle for each cylinder accordingly.

Is the harness wired according to the firing order?

The Clubsport System is defined to have the first cylinder in the firing order connected to the output A, the second to output B and so on. This is the recommended wiring configuration. In this case, your TDC angles must be input in ascending order.

First make sure you have installed the calibration software following the instructions provided. Then follow these steps:

1. Look for the characteristic value CYLNUMBER and enter the cylinder number of your engine.
2. If the crankshaft wheel has 36-2 teeth set CRANKWHEEL36 to 1. If it has 60-2 set it to 0 (default value).
3. Enter the TDC angles for each cylinder according to the convention defined above in TDCCYL1 to TDCCYLN where N is the number of cylinders of the engine.

Example 1

To better understand this process a symmetrical 6 cylinder engine with a standard crankshaft wheel will be described. The first TDC is 78° from the second tooth after the gap. In this case the following parameters must be input:

CYLNUMBER = 6
CRANKWHEEL36 =0
TDCCYL1 = 78
TDCCYL2 = 198
TDCCYL3 = 318
TDCCYL4 = 438
TDCCYL5 = 558
TDCCYL6 = 678

Notice that the angle between each TDC is 120° because the engine has symmetrical ignition.

Example 2

Now suppose the same engine has a V configuration 90°-150°. In this case the TDC angles are:

TDCCYL1 = 78
TDCCYL2 = 168
TDCCYL3 = 318
TDCCYL4 = 408
TDCCYL5 = 558
TDCCYL6 = 648

4.1.2 Injection: INJCALC

TIBAT_OFF Battery voltage correction. Predefined value for Bosch Type valves EV6, characteristics can be requested by the valve manufacturer.

TI_FAK Global factor, set to 1.0 for startup.

4.1.2.1 Injection Map

TI_DEF Base Injection timing in milliseconds.

The injection time depends mainly on throttle position, engine speed, fuel pressure and injection valve type. To get a first estimation, the following characteristics must be known:

- displacement per cylinder V_c (m³)
- expected intake manifold pressure (after throttle) p_i [Pa]
- desired lambda value λ
- operating fuel pressure p_f [bar]
- injection valve flow rate Q_{stat} [g/min] at reference fuel pressure p_{fRef} [bar]
- intake air temperature T_i [K]

The fuel mass m_f is calculated by:

$$m_f = \frac{p_i \cdot V_c}{R \cdot T_i} \cdot \frac{1}{14.5} \cdot \frac{1}{\lambda} \quad [\text{kg}] \quad \text{with } R = 287 \text{ [J/kg] constant}$$

The energizing time of the injection valves is calculated by:

$$t_i = \frac{m_f}{Q_{stat}} \cdot \sqrt{\frac{p_{fRef}}{p_f}} \cdot 10^6 \cdot 60 \quad [\text{ms}]$$

TITAIR_FAK Correction by intake air temperature. This value is predefined. If unsure, set it to 1.0 constantly for first startup.

TITMOT_FAK Correction by engine coolant temperature. This value is predefined. If unsure, set it to 1.0 constantly for first startup.


TIPFUEL_FAK Correction by fuel pressure. This value is predefined. If unsure, set it to 1.0 constantly for first startup.

TIREVPCORR_FAK Correction by ambient pressure / airbox pressure. This value is predefined. If unsure, set it to 1.0 constantly for first startup.

PCORR_CW Select correction mode. Ambient (0) or airbox (1) pressure.

4.1.2.2 Cylinder Individual

CYLBANK_CW Lambda control is done bankwise, therefore this adjustment must be done for proper lambda control. Open the label and allocate the cylinders to the right bank via dropdown menu.



Note: Engines with one lambda sensor (e.g. 4-in-a-row) run as 1-Bank-Systems. Set CYLBANK_CW to 0.

TIREVATH_FAK_x Cylinder individual corrections. Set to 1.0 for first startup. Numbering refers to firing order!

INJOFFPATTERN Torque reduction by injection fade out. Different, repeating fade out patterns can be defined for several full power strokes of the engine (720° crank or 2 full rotations). This prevents single cylinders from cooling down too much and makes it possible to find optimal patterns.

Example 4 cylinder engine:

fade out level injoff →

y/x	0	1	2	3	4
0	0	1 (=0001b)	3 (=0011b)	7 (=0111b)	15 (=1111b)
1	0	2 (=0010b)	12 (=1100b)	7 (=0111b)	15 (=1111b)
2	0	4 (=0100b)	3 (=0011b)	14(=1110b)	15 (=1111b)
3	0	8 (=1000b)	12 (=1100b)	13(=1110b)	15 (=1111b)

The cylinders are assigned bitwise, the lowest bit represents cylinder 1 in firing order (FO1), e.g. injoff = 1:

- First power stroke 0°-720°: Cylinder 1 (FO1) is faded out
- Second power stroke 720°-1440°: Cylinder 2 (FO2) is faded out
- Third Power stroke 1440°-2160°: Cylinder 3 (FO3) is faded out
- Fourth Power stroke 2160°-2880°: Cylinder 4 (FO4) is faded out
- Fifth Power stroke 2880°-3600°: Cylinder 1 (FO1) is faded out
- ...

4.1.2.3 Injection Start

TISTARTBASE Base injection time for engine start. Can be set to a value near full load from the maps TI_MIN/DEF/MAX in atmospheric engines. Scale down proportional to boost pressure for turbo engines.

Further corrections: Predefined. If unsure, set to 1.0 for first startup.

4.1.2.4 Injection Angle

- INJANGREVATH** End of injection pulse, refers to combustion TDC. Make sure, the injection is ended before the inlet valve closes. Try 200° - 300° for first startup.
- INJANGSTREV** End of injection pulse in engine start. Refer to INJANGREVATH.

4.1.3 Injection Controls

4.1.3.1 LAMCTRL

- LAMCTRL_CW** Deactivate by setting = 0.
- LAM_MIN** Desired Lambda map, map-switch dependant.
LAM-DEF
LAM-MAX

4.1.3.2 INJCUT

- INJCUTGEAR** Deactivate by setting = 0.0.

4.1.3.3 INJENRICH

- INJENRICHREV_MIN** Deactivate by setting = 32768.

4.1.4 Ignition: IGNCALC

Important note: Positive values stand for ignition angles before TDC, negative values after TDC. Begin with moderate values to protect your engine from damages.

- IGNSTARTREV** Base spark advance in engine start. Set to 5 – 10 deg.
- IGNSTARTTMOT_OFF** Correction by engine coolant temperature. Set to 0.0 for first startup.
- TDWELLBATTREV** Coil dwell time. Consult the coil manufacturer for details. Most coils need dwell times about 1.5 to 2.5 milliseconds at 12 – 14 V.
- TDWELLMAX_OFF** Dwell time limitation. Stay with predefined value for first startup.
- IGNREV_OFF_x** Cylinder individual correctons. Set to 0.0. Numbering refers to firing order!

4.1.4.1 IGNITION_MAPS

IGN_MIN Base Injection timing in deg crankshaft before TDC, map-switch dependant. Use modest values at the first time. Atmospheric engines may run safe at 20 – 25 deg in part load, Turbo engines at high boosts may demand even less spark advance. These values are strongly dependant on compression ratio, fuel quality, temperature and engine specifics. If you know you're using "bad" fuel, run at high temperatures or your engine is very sensitive on spark advance, go to the safe side.

IGN_DEF

IGN_MAX

Further corrections: Predefined. If unsure, set to 0.0 for first startup.

4.1.5 Inj + Ign Controls:

4.1.5.1 GEARCUT:

GCREV_THR Deactivate by setting = 32768.

4.1.5.2 REVLIMIT:

The Rev-Limiter works in three steps:

- Soft limitation by ignition retardation
- Hard limitation by Injection cut off
- Absolute limitation by full injection and ignition cut off

REVLIMITSOFTGEAR Soft limiter, gear dependant: Apply the revs at which the limiter shall become active (same value to all gear break points on dyno).

IGNREVLIMITSOFT Apply the ignition angle (absolute) dependant on the engine overspeed (rev – REVLIMITSOFTGEAR).

REVLIMITHARDGEAR Exceeding this values, the injection will be cut off.

REVLIMITIGNOFF_OFF Maximum overspeed relative to REVLIMITHARDGEAR. Injection and ignition fade out when exceeded.

4.1.5.3 SPEEDLIMIT:

SPEEDLIMITREV_MIN Deactivate by setting = 32768.

4.1.5.4 TRACTIONCTRL:

TC_CW Deactivate by setting = 0.

4.2 Online Data Application

Sensors and peripherals can be checked when the system is powered up electrically. Do not start the engine before all steps in this chapter are carried out. Make sure the battery is connected properly, all sensors are connected, ground wiring is fixed before powering up the system. Check all sensors for errors (bits ..._e) before starting the engine.

4.2.1 PRESSURES

All pressures are calculated in the same way. The system offers oil pressure (poil), ambient pressure (pamb), crank pressure (pcrank) and fuel pressure (pfuel).

Example: Ambient pressure

PAMB_OFF, PAMB_GRD	Sensor offset and gradient. Consult the sensor manufacturer for details.
PAMB_UMX, PAMB_UMN	Maximum and minimum accepted sensor voltage. When violated, an error is set (pamb_e = 1). Set to approx. 250 mV / 4750 mV.
PAMB_DEF	Default value. If a sensor error is set, the output is switched to the default.
PAMB_FIL	Filter constant. Use modest values, ~ 10 - 40 milliseconds.
All other variables	All other variables are named by the same rule, replace “pamb” by e.g. “poil” to apply data for the oil pressure sensor.

4.2.2 TEMPERATURES

All temperatures are calculated in the same way. The system offers oil temperature (toil), intake air temperature (tair), engine temperature (tmot), fuel temperature (tfuel), ...

Example: Intake air temperature

TAIR_UMX, TAIR_UMN	Maximum and minimum accepted sensor voltage. When violated, an error is set (tair_e = 1). Set to approx. 200 mV / 4800 mV.
TAIR_LIN	Sensor characteristic. Consult the sensor manufacturer.

4.2.3 LAMDET

LAMTYPE_CW	Select the sensor type: LSU4.2 (set to 0) or LSU4.9 (set to 1).
All other labels	Keep the predefined values.

4.2.4 GEARDET

Refer the function description if needed. For engine application not necessary.

4.2.5 ATHDET

ATH_UMN, Maximum and minimum accepted sensor voltage. When violated, an error is
ATH_UMX set (ath_e = 1). Set to approx. 250 mV / 4750 mV.

Check if the sensor output value ath_u is changing when throttle is moved.

4.2.5.1 CALIBRATION:

ATHPOS1 Lower calibration point, set to 0.0 %.

ATHPOS2 Full load point, set to 100.0 %.

ATHIDLECAL Set to desired idle ath value.

ATH_CW Close throttle and set ATH_CW to 1.
Open throttle fully and set ATH_CW to 2.
Set throttle to idle point and set ATH_CW to 3.

Check calibration by moving throttle.

5 Extensibility

We developed a lot of extras for the ecus. That is e.g.:

- Displays
- Data loggers
- Telemetry units

Find more information on our website at www.bosch-motorsport.com

Moreover, you can expand some additional functions of your ecu by sending us the serial number.


Then we will send you the licence for:

- Traction control
- Drive by wire
- Knock control

6 Activation of Softwareoptions

If you buy optional software, you will get a codenumber with eight ciphers from us. We enable this codenumber exclusively for one defined ECU-serialnumber. It will work with this ECU only.

Start the application tool Modas Sport. You will find a predefined worksheet called **Licence** there, see picture below.



Example code: 02E2 B875

Fill in the first four ciphers of your licence code (here 02E2) into the input box LICMANKEYHIGH (1)

Fill in the last four ciphers of your licence code (here B875) into the input box LICMANKEYLOW (2)

If you have filled in the right licence code, the according softwareoption will be set on TRUE (3).

Exception: Near Bank/Far Bank and VVT. These functions require an ECU-software-update. Please contact us for more information.

Contact

Europe:

Bosch Engineering GmbH
Motorsport
Robert-Bosch-Allee 1
74232 Abstatt
Germany
Phone: +49 7062 911 79101
Fax: +49 7062 911 79104

North and South America:

Bosch Engineering North America
Motorsports
38000 Hills Tech Drive
Farmington Hills, MI 48331-3417
United States of America
Phone: +1 248 876 2977
Fax: +1 248 876 7373

Asia Pacific:

Bosch Engineering K.K.
Motorsport
3-33-8 Tsuruya-cho, Kanagawa-ku, Yokohama-shi
221-0835
Japan
Phone: +81 45 410 1650
Fax: +81 45 410 1651

E-Mail: motorsport@bosch.com
www.bosch-motorsport.com

Status: 08 February 2012

*© All rights reserved by Bosch Engineering GmbH,
also for the case of patent reports.
All rights such as copying and forwarding through us.
Modifications reserved.*



BOSCH