

Potiboard POP (Parameter Operating Panel)

POP is part of the INCA module family. It is designed for online mapping on dyno supporting the INCA calibration function. POP is coupled to the PC via serial link on the SMB bus.



Details

Robust design

External power supply

Modification of calibration data by potentiometer operation

4 potentiometers, individual assignment to 4 characteristic values (fixed values, characteristic lines or maps)

Additive or multiplicative modification selectable

POP configuration saved together with the INCA display

Order number

B 261 206 428